SUBARU

ADDED SECURITY®



Subaru Easy-View Plan Comparison Guide. Added Security. The only coverage backed by Subaru.

SUBARU

What is **Added Security®?**

Added Security is the only mechanical breakdown coverage backed by Subaru of America, Inc. Because almost every Subaru includes advanced, complex systems such as EyeSight® Driver Assist Technology, it's important to consider our Gold Plus Plan, which covers all of the intricate components that can be very expensive to replace.

With all Added Security plans, if a covered component breaks, our certified Subaru technicians will fix it using only new or remanufactured Genuine Subaru Parts. Unlike third-party plans, Added Security also covers wear and tear of covered components, consequential damage to other components, struts, constant-velocity joints and many more parts. Plus, all Subaru Certified Pre-Owned vehicles come with our Powertrain Coverage Plan, which can be upgraded to the Gold Plus Plan for up to 10 years.[1]

Added Security provides peace of mind that you're still protected after the warranty expires.

There are two main plans:

Classic Plan: Stated coverage for most major components.

Gold Plus Plan: Covers everything but a small list of maintenance items and body trim. See the agreement or application for details.



Plans include:

Roadside Assistance

Services such as towing, jumpstarts and flat tire changes are included in some plans. See the agreement/ application for details.

Towing Allowance

All plans provide an allowance if you need a tow due to a covered failure.

Rental Car Allowance

All plans provide an allowance for up to five days if your Subaru needs to be kept in the shop overnight for a covered repair.

The Gold Plus Plan also includes:

Trip Interruption Allowance

The Gold Plus Plan provides coverage of up to $500 (per occurrence) toward your hotel and meals if you break down. While most third-party plans require the breakdown to be more than 100 miles from home, Gold Plus Plans cover you starting at 50 miles (or more) from home.

Additional Services

Maintenance Plans

You can lock in the cost of regularly scheduled maintenance by including one of our Maintenance Plans when you purchase your Subaru. Simply select the plan that aligns with your vehicle's recommended maintenance schedule. Also, every new-car Added Security Maintenance Plan includes a coupon worth $500 towards the purchase of your next new Subaru.[2]

1 From vehicle's original warranty start date. 2 Excluding promotional plans and Anytime Maintenance plans.

Gold Plus Coverage*

Our widest-ranging plan includes **all Classic and Powertrain coverage, plus virtually every other part of your Subaru—**even the components of its most sophisticated technologies.

Coverage includes:

- **EyeSight Driver Assist Technology[1]**
- **Blind-Spot Detection[2]**
- **Rear Cross-Traffic Alert[2]**
- **Reverse Automatic Braking[3]**
- **DriverFocus® Distraction Mitigation System[4]**
- **STARLINK™ Multimedia**
- **STARLINK™ Safety and Security[5]**

Coverage also includes:

Air Bypass Valve
Air Flow Meter
Timing Chain Tensioner
Timing Chain Guide
Front Engine Mounting Bracket
Fuel Injection System, including Injectors
Intake Manifold
Intercooler and Duct
Turbocharger Housing
Turbo Inlet Elbow
Wastegate Controller
DCCD Center Differential
DCCD Manual Switch, Control Dial, Relay and Control Module
Steering Angle Sensor
Roll Connector
Double Offset Joints
Rear Differential Assembly and internal parts
Ambient Sensor
Coolant Crossover and Pipe
Coolant Heater Pipe
Engine Fans
Engine Oil Cooler Lines and Mounting Bolt
Fan Control Amplifier
Engine Temperature Sensor
Heater Core Inlet/Outlet Pipe
Idler Pulley
In-Vehicle Sensor
Radiator Fan Control Unit
Radiator Reserve Tank and Bracket
Sun Load Sensor
Thermostat and Thermostat Housing
Throttle Body Coolant Pipe
Turbo Oil Delivery and Return Pipes
Turbo Oil Scavenge Pump
Water Bypass Pipe
Water Pump Pulley
Air Cleaner Housing
Air Intake Resonator and Duct
Air Supply System
Crankcase Vent Pipe
EGR Pipe and Heat Shield
EGR Modulator Valve and Manifold
EGR Cooler
Electronic Throttle Body Assembly
Fuel Evaporative Pipe and Clamp
Fuel Chamber, Damper and Cut Valve
Fuel Filler Hose, Clamp, Cap and Pipe Fuel Lines
Fuel Tank
Vent Cover, Hose and Pipe
Rollover Valve
Two-Way Switch and Valve
Turbo Air Bypass Valve
Vapor Separator
Vacuum Pipe Assembly
Rear Cooling Unit Blower Motor
Receiver/Dryer
Accelerator Switch
Accelerator Pedal Return Spring Switch
Accelerator Pedal, Lever, Clip and Bracket
Auto Transmission Oil Cooler
Clutch Release
Clutch Fork Boot and Return Spring
Clutch Operating Cylinder
Clutch Hydraulic Line and Gasket
Clutch Master Cylinder and Connecting Link
Clutch Pedal, Washer and Bushing
Differential Dip Stick
Speed Sensor
Inhibitor Switch
Paddle Shifter
Key Lock Solenoid and Release Lever
Oil Temperature Switch
Park Switch
Pilot Bearing
Selector Cable, Linkage, Bushing and Clip
Selector Cable Pin and Bushing
Shift Lock Control Unit, Lever and Solenoid
Stop Light Switch
Transmission Revolution Sensor
Connecting Link
Crossmember Bushing
Front Strut Mount, Cover and Spring
Front Crossmember Support and Bracket
Hub Bearing Unit
Hub Bolt
Blower Motor Resistor
Blower Motor Transistor
Brake Fluid Indicator Switch
Cam Angle Sensor
Circuit Board
Clutch Switch
Crank Angle Sensor
Dash Warning Box
Electric Parking Brake Actuator
Duty Solenoid
ECU Unit
EGR Temperature Sensor
Cruise Control Electronic Module
Power Rear Gate Control Module
Power Rear Gate Drive Motor
Power Rear Gate Auto Closer
Fuse Box
Fuse Joint Box
GPS Antenna
Hand/Foot Brake Switch
Headlamp Adjuster Switch
Headlamp Adjuster Motor
Headlight Illumination Sensor
Auto Headlight Leveler CM
Heater Blower Fresh Air Actuator
Heater Blower Motor
Rear Heater Blower
Heater Mode Control Unit and Actuator
Ignition Key Light
Inner Lap Belt Switch
Intake Air Temp Sensor
Immobilizer Antenna and Transponder
Key/Seatbelt Warning Chime
Manifold Absolute Pressure Sensor
Manual Transmission Neutral Switch
Knock Sensor
Multifunction Display
Navigation Display
Navigation Unit and Bracket
Outside Temp. Sensor
Oxygen Sensor
Power Door Locks
Power Seat Limit Switch
Power Seat Linkage
Power Seat Reclining Motor
Power Seat Tilt Motors
Power Seat Slide Rail Motor
Power Sunroof Micro Switch and Control Unit
Power Window Circuit Breaker
Rear Window Washer Pump
Rear Window Defogger Grid
Rear Wiper Intermittent Unit
Body Integrated Unit
Rear Cooling Unit Switch
Seatbelt Switch
Seatbelt Warning Chime
Shoulder Belt Switch
Starter Interlock Switch
Trunk Light Switch
Turbo Air Temperature Sensor
Turbo Boost Sensor
Voltage Drop Resistor
Warning Unit Display
Wastegate Control Valve
Window Regulators
Center Console Latch
Dash Speakers
Front Seatbelt Set
Radio
Qi® Charging Pad[6]
Front Seat Lift Frame and Side Rails
Glove Box Latch and Striker
Keyless Entry Transmitter
Rear Shelf Speakers
Security System Control and Receiver Modules
Sunroof Track, Cable and Guide
Third-Row Seatbelt Set
Third-Row Seat Back Frame and Hinge
Tire Pressure Monitoring System
Transmitter and Control Module
Valve Body

And many more components

For illustration purposes only.

*Added Security Gold Plus does not cover some components, including maintenance items, glass, brake pads, windshield wiper blades, hoses, belts, batteries and more. Please see your Subaru retailer for specific component coverage details.

SUBARU ADDED SECURITY®

Powertrain Coverage

Powertrain coverage is offered on every Subaru CPO vehicle. This coverage includes engine, transaxle and differential components. Optional Gold Plus coverage for up to 10 years is available.

Classic Coverage

To protect your investment beyond the standard Subaru Warranty, **Classic includes all Powertrain coverage, plus additional specific components/major systems.**

Coverage includes:

- Cooling & Fuel
- Brakes
- Steering
- Electrical Systems
- Suspension
- Air Conditioning

Electrical Systems

With Gold Plus Plans, covers all on-board technology and electrically powered components. Some wiring covered by Classic plans. See applications for details.

Other Products

Subaru Equity Shield

Optimum Vehicle Protection (OVP)*

These additional protections can be purchased separately:

- Tire and Wheel Protection
- Windshield Protection
- Dent and Ding Protection
- Key Fob Protection

*See program details for further information, exclusions and state availability.

Other Products

Subaru Equity Shield

Optimum Vehicle Protection (OVP)*

These additional protections can be purchased separately:

- Tire and Wheel Protection
- Windshield Protection
- Dent and Ding Protection
- Key Fob Protection

*See program details for further information, exclusions and state availability.



For illustration purposes only.

Electrical Systems

With Gold Plus Plans, covers all on-board technology and electrically powered components. Some wiring covered by Classic plans. See applications for details.

Gold Plus Coverage*

Our widest-ranging plan includes **all Classic and Powertrain coverage, plus virtually every other part of your Subaru—**even the components of its most sophisticated technologies.

Coverage includes:

- **EyeSight Driver Assist Technology[1]**
- **Blind-Spot Detection[2]**
- **Rear Cross-Traffic Alert[2]**
- **Reverse Automatic Braking[3]**
- **DriverFocus® Distraction Mitigation System[4]**
- **STARLINK™ Multimedia**
- **STARLINK™ Safety and Security[5]**

Coverage also includes:

Air Bypass Valve
Air Flow Meter
Timing Chain Tensioner
Timing Chain Guide
Front Engine Mounting Bracket
Fuel Injection System, including Injectors
Intake Manifold
Intercooler and Duct
Turbocharger Housing
Turbo Inlet Elbow
Wastegate Controller
DCCD Center Differential
DCCD Manual Switch, Control Dial, Relay and Control Module
Steering Angle Sensor
Roll Connector
Double Offset Joints
Rear Differential Assembly and internal parts
Ambient Sensor
Coolant Crossover and Pipe
Coolant Heater Pipe
Engine Fans
Engine Oil Cooler Lines and Mounting Bolt
Fan Control Amplifier
Engine Temperature Sensor
Heater Core Inlet/Outlet Pipe
Idler Pulley
In-Vehicle Sensor
Radiator Fan Control Unit
Radiator Reserve Tank and Bracket
Sun Load Sensor
Thermostat and Thermostat Housing
Throttle Body Coolant Pipe
Turbo Oil Delivery and Return Pipes
Turbo Oil Scavenge Pump
Water Bypass Pipe
Water Pump Pulley
Air Cleaner Housing
Air Intake Resonator and Duct
Air Supply System
Crankcase Vent Pipe
EGR Pipe and Heat Shield
EGR Modulator Valve and Manifold
EGR Cooler
Electronic Throttle Body Assembly
Fuel Evaporative Pipe and Clamp
Fuel Chamber, Damper and Cut Valve
Fuel Filler Hose, Clamp, Cap and Pipe Fuel Lines
Fuel Tank
Vent Cover, Hose and Pipe
Rollover Valve
Two-Way Switch and Valve
Turbo Air Bypass Valve
Vapor Separator
Vacuum Pipe Assembly
Rear Cooling Unit Blower Motor
Receiver/Dryer
Accelerator Switch
Accelerator Pedal Return Spring Switch
Accelerator Pedal, Lever, Clip and Bracket
Auto Transmission Oil Cooler
Clutch Release
Clutch Fork Boot and Return Spring
Clutch Operating Cylinder
Clutch Hydraulic Line and Gasket
Clutch Master Cylinder and Connecting Link
Clutch Pedal, Washer and Bushing
Differential Dip Stick
Speed Sensor
Inhibitor Switch
Paddle Shifter
Key Lock Solenoid and Release Lever
Oil Temperature Switch
Park Switch
Pilot Bearing
Selector Cable, Linkage, Bushing and Clip
Selector Cable Pin and Bushing
Shift Lock Control Unit, Lever and Solenoid
Stop Light Switch
Transmission Revolution Sensor
Connecting Link
Crossmember Bushing
Front Strut Mount, Cover and Spring
Front Crossmember Support and Bracket
Hub Bearing Unit
Hub Bolt
Blower Motor Resistor
Blower Motor Transistor
Brake Fluid Indicator Switch
Cam Angle Sensor
Circuit Board
Clutch Switch
Crank Angle Sensor
Dash Warning Box
Electric Parking Brake Actuator
Duty Solenoid
ECU Unit
EGR Temperature Sensor
Cruise Control Electronic Module
Power Rear Gate Control Module
Power Rear Gate Drive Motor
Power Rear Gate Auto Closer
Fuse Box
Fuse Joint Box
GPS Antenna
Hand/Foot Brake Switch
Headlamp Adjuster Switch
Headlamp Adjuster Motor
Headlight Illumination Sensor
Auto Headlight Leveler CM
Heater Blower Fresh Air Actuator
Heater Blower Motor
Rear Heater Blower
Heater Mode Control Unit and Actuator
Ignition Key Light
Inner Lap Belt Switch
Intake Air Temp Sensor
Immobilizer Antenna and Transponder
Key/Seatbelt Warning Chime
Manifold Absolute Pressure Sensor
Manual Transmission Neutral Switch
Knock Sensor
Multifunction Display
Navigation Display
Navigation Unit and Bracket
Outside Temp. Sensor
Oxygen Sensor
Power Door Locks
Power Seat Limit Switch
Power Seat Linkage
Power Seat Reclining Motor
Power Seat Tilt Motors
Power Seat Slide Rail Motor
Power Sunroof Micro Switch and Control Unit
Power Window Circuit Breaker
Rear Window Washer Pump
Rear Window Defogger Grid
Rear Wiper Intermittent Unit
Body Integrated Unit
Rear Cooling Unit Switch
Seatbelt Switch
Seatbelt Warning Chime
Shoulder Belt Switch
Starter Interlock Switch
Trunk Light Switch
Turbo Air Temperature Sensor
Turbo Boost Sensor
Voltage Drop Resistor
Warning Unit Display
Wastegate Control Valve
Window Regulators
Center Console Latch
Dash Speakers
Front Seatbelt Set
Radio
Qi® Charging Pad[6]
Front Seat Lift Frame and Side Rails
Glove Box Latch and Striker
Keyless Entry Transmitter
Rear Shelf Speakers
Security System Control and Receiver Modules
Sunroof Track, Cable and Guide
Third-Row Seatbelt Set
Third-Row Seat Back Frame and Hinge
Tire Pressure Monitoring System
Transmitter and Control Module
Valve Body

And many more components



For illustration purposes only.

*Added Security Gold Plus does not cover some components, including maintenance items, glass, brake pads, windshield wiper blades, hoses, belts, batteries and more. Please see your Subaru retailer for specific component coverage details.



For illustration purposes only.

Classic Coverage

To protect your investment beyond the standard Subaru Warranty, **Classic includes all Powertrain coverage, plus additional specific components/major systems.**

Coverage includes:

- Cooling & Fuel
- Steering
- Suspension
- Brakes
- Electrical Systems
- Air Conditioning



For illustration purposes only.

Powertrain Coverage

Powertrain coverage is offered on every Subaru CPO vehicle. This coverage includes engine, transaxle and differential components. Optional Gold Plus coverage for up to 10 years is available.

Gold Plus Coverage*

Our widest-ranging plan includes **all Classic and Powertrain coverage, plus virtually every other part of your Subaru—**even the components of its most sophisticated technologies.

Coverage includes:

- **EyeSight Driver Assist Technology[1]**
- **Blind-Spot Detection[2]**
- **Rear Cross-Traffic Alert[2]**
- **Reverse Automatic Braking[3]**
- **DriverFocus® Distraction Mitigation System[4]**
- **STARLINK™ Multimedia**
- **STARLINK™ Safety and Security[5]**

Coverage also includes:

Air Bypass Valve
Air Flow Meter
Timing Chain Tensioner
Timing Chain Guide
Front Engine Mounting Bracket
Fuel Injection System, including Injectors
Intake Manifold
Intercooler and Duct
Turbocharger Housing
Turbo Inlet Elbow
Wastegate Controller
DCCD Center Differential
DCCD Manual Switch, Control Dial, Relay and Control Module
Steering Angle Sensor
Roll Connector
Double Offset Joints
Rear Differential Assembly and internal parts
Ambient Sensor
Coolant Crossover and Pipe
Coolant Heater Pipe
Engine Fans
Engine Oil Cooler Lines and Mounting Bolt
Fan Control Amplifier
Engine Temperature Sensor
Heater Core Inlet/Outlet Pipe
Idler Pulley
In-Vehicle Sensor
Radiator Fan Control Unit
Radiator Reserve Tank and Bracket
Sun Load Sensor
Thermostat and Thermostat Housing
Throttle Body Coolant Pipe
Turbo Oil Delivery and Return Pipes
Turbo Oil Scavenge Pump
Water Bypass Pipe
Water Pump Pulley
Air Cleaner Housing
Air Intake Resonator and Duct
Air Supply System
Crankcase Vent Pipe
EGR Pipe and Heat Shield
EGR Modulator Valve and Manifold
EGR Cooler
Electronic Throttle Body Assembly
Fuel Evaporative Pipe and Clamp
Fuel Chamber, Damper and Cut Valve
Fuel Filler Hose, Clamp, Cap and Pipe Fuel Lines
Fuel Tank
Vent Cover, Hose and Pipe
Rollover Valve
Two-Way Switch and Valve
Turbo Air Bypass Valve
Vapor Separator
Vacuum Pipe Assembly
Rear Cooling Unit Blower Motor
Receiver/Dryer
Accelerator Switch
Accelerator Pedal Return Spring Switch
Accelerator Pedal, Lever, Clip and Bracket
Auto Transmission Oil Cooler
Clutch Release
Clutch Fork Boot and Return Spring
Clutch Operating Cylinder
Clutch Hydraulic Line and Gasket
Clutch Master Cylinder and Connecting Link
Clutch Pedal, Washer and Bushing
Differential Dip Stick
Speed Sensor
Inhibitor Switch
Paddle Shifter
Key Lock Solenoid and Release Lever
Oil Temperature Switch
Park Switch
Pilot Bearing
Selector Cable, Linkage, Bushing and Clip
Selector Cable Pin and Bushing
Shift Lock Control Unit, Lever and Solenoid
Stop Light Switch
Transmission Revolution Sensor
Connecting Link
Crossmember Bushing
Front Strut Mount, Cover and Spring
Front Crossmember Support and Bracket
Hub Bearing Unit
Hub Bolt
Blower Motor Resistor
Blower Motor Transistor
Brake Fluid Indicator Switch
Cam Angle Sensor
Circuit Board
Clutch Switch
Crank Angle Sensor
Dash Warning Box
Electric Parking Brake Actuator
Duty Solenoid
ECU Unit
EGR Temperature Sensor
Cruise Control Electronic Module
Power Rear Gate Control Module
Power Rear Gate Drive Motor
Power Rear Gate Auto Closer
Fuse Box
Fuse Joint Box
GPS Antenna
Hand/Foot Brake Switch
Headlamp Adjuster Switch
Headlamp Adjuster Motor
Headlight Illumination Sensor
Auto Headlight Leveler CM
Heater Blower Fresh Air Actuator
Heater Blower Motor
Rear Heater Blower
Heater Mode Control Unit and Actuator
Ignition Key Light
Inner Lap Belt Switch
Intake Air Temp Sensor
Immobilizer Antenna and Transponder
Key/Seatbelt Warning Chime
Manifold Absolute Pressure Sensor
Manual Transmission Neutral Switch
Knock Sensor
Multifunction Display
Navigation Display
Navigation Unit and Bracket
Outside Temp. Sensor
Oxygen Sensor
Power Door Locks
Power Seat Limit Switch
Power Seat Linkage
Power Seat Reclining Motor
Power Seat Tilt Motors
Power Seat Slide Rail Motor
Power Sunroof Micro Switch and Control Unit
Power Window Circuit Breaker
Rear Window Washer Pump
Rear Window Defogger Grid
Rear Wiper Intermittent Unit
Body Integrated Unit
Rear Cooling Unit Switch
Seatbelt Switch
Seatbelt Warning Chime
Shoulder Belt Switch
Starter Interlock Switch
Trunk Light Switch
Turbo Air Temperature Sensor
Turbo Boost Sensor
Voltage Drop Resistor
Warning Unit Display
Wastegate Control Valve
Window Regulators
Center Console Latch
Dash Speakers
Front Seatbelt Set
Radio
Qi® Charging Pad[6]
Front Seat Lift Frame and Side Rails
Glove Box Latch and Striker
Keyless Entry Transmitter
Rear Shelf Speakers
Security System Control and Receiver Modules
Sunroof Track, Cable and Guide
Third-Row Seatbelt Set
Third-Row Seat Back Frame and Hinge
Tire Pressure Monitoring System
Transmitter and Control Module
Valve Body

And many more components



For illustration purposes only.

*Added Security Gold Plus does not cover some components, including maintenance items, glass, brake pads, windshield wiper blades, hoses, belts, batteries and more. Please see your Subaru retailer for specific component coverage details.

SUBARU ADDED SECURITY®

Powertrain Coverage

Powertrain coverage is offered on every Subaru CPO vehicle. This coverage includes engine, transaxle and differential components. Optional Gold Plus coverage for up to 10 years is available.

Classic Coverage

To protect your investment beyond the standard Subaru Warranty, **Classic includes all Powertrain coverage, plus additional specific components/major systems.**

Coverage includes:

- Cooling & Fuel
- Steering
- Suspension
- Brakes
- Electrical Systems
- Air Conditioning

Electrical Systems

With Gold Plus Plans, covers all on-board technology and electrically powered components. Some wiring covered by Classic plans. See applications for details.

Other Products

Subaru Equity Shield

Optimum Vehicle Protection (OVP)*

These additional protections can be purchased separately:

- Tire and Wheel Protection
- Windshield Protection
- Dent and Ding Protection
- Key Fob Protection

*See program details for further information, exclusions and state availability.

Subaru Equity Shield

Optimum Vehicle Protection (OVP)*

TIRE AND WHEEL PROTECTION

Coverage for tire repair or replacement or wheel replacement due to covered road hazard

WINDSHIELD PROTECTION

Covers Windshield Repairs (cracks, chips, bullseyes) under 6 inches long

DENT AND DING PROTECTION

Covers Paintless Dent Repair (and hail damage up to $1,000 of insurance deductible)

All OVP products have: unlimited claims, zero deductible and no aggregate limits.

*See program details for further information, exclusions and state availability.

Classic

ENGINE

- Valve Covers
- Oil Sending Unit
- Motor Mounts
- Turbocharger Assembly
- Fuel Injection System
- Oil Pump and Oil Pan
- Timing Belts or Gears and Cover
- Water Pump
- Intake and Exhaust Manifolds
- Oil Seals and Gaskets

TRANSMISSION

- Transmission Mounts
- Torque Converter
- Flywheel

ALL-WHEEL DRIVE

- Constant Velocity Joint Boots
- Center Support Bearings
- Universal Joints
- Wheel Bearings and Spindle Rear
- Torsion Bars
- Rear Control Arms
- Hub Bearings

TRANSAXLE AND DIFFERENTIAL

- Transaxle Case and internal parts
- Electronic Transmission Control Unit
- Seals and Gaskets
- Axle Shafts and Constant Velocity Joints
- Propeller Shaft

COOLING AND FUEL

- Radiator
- Heater Core
- Engine Fan and Heater Fan
- Fuel Pump
- Fuel Lines
- Fuel Tank
- Fuel Sending Unit

STEERING

- Steering Rack Assembly and all internal parts
- Steering Column Shaft and Coupling
- Universal Joints
- Power Steering Pump
- Seals and Gaskets

FRONT SUSPENSION

- MacPherson Struts
- Transverse Links/Control Arms
- Shafts and Bushings
- Ball Joints
- Steering Knuckles
- Wheel Bearings
- Stabilizer Bar and Bushings Seals and Gaskets

BRAKES

- Master Cylinder
- Power Brake Assist Unit
- Anti-lock Braking System
- Traction Control System
- Wheel Cylinders
- Hydraulic Lines and Fittings
- Disc Brake Calipers
- Seals and Gaskets

ELECTRICAL

- Alternator
- Voltage Regulator
- Ignition Coil
- Starter Motor & Solenoid
- Wiring Harnesses
- Engine Management Control Unit
- Power Door Locks
- Sunroof Motor
- Power Window Motors and Regulators
- Power Mirror Motors
- Windshield Wiper Motors
- Heater Blower Motor and Switch
- Electronic Instrument Display
- Trip Computer
- Clock
- Analog Dash Gauges
- Speedometer Head
- Horns
- Electronic Relays
- Manually Operated Switches

AIR CONDITIONING

- Compressor
- Clutch and Pulley
- Condenser
- Evaporator
- Expansion Valve (Orifice)
- Blower Motor
- Compressor Seal
- Receiver/Dryer

Gold Plus*

- Air Bypass Valve
- Air Flow Meter
- Timing Chain Tensioner
- Timing Chain Guide
- Front Engine Mounting Bracket
- Fuel Injection System, including Injectors
- Intake Manifold
- Intercooler and Duct
- Turbocharger Housing
- Turbo Inlet Elbow
- Wastegate Controller
- DCCD Center Differential
- DCCD Manual Switch, Control Dial, Relay and Control Module
- Steering Angle Sensor
- Roll Connector
- Double Offset Joints
- Rear Differential Assembly and internal parts
- Ambient Sensor
- Coolant Crossover and Pipe
- Coolant Heater Pipe
- Engine Fans
- Engine Oil Cooler Lines and Mounting Bolt
- Fan Control Amplifier
- Engine Temperature Sensor
- Heater Core Inlet/Outlet Pipe
- Idler Pulley
- In-Vehicle Sensor
- Radiator Fan Control Unit
- Radiator Reserve Tank and Bracket
- Sun Load Sensor
- Thermostat and Thermostat Housing
- Throttle Body Coolant Pipe
- Turbo Oil Delivery and Return Pipes
- Turbo Oil Scavenge Pump
- Water Bypass Pipe
- Water Pump Pulley
- Air Cleaner Housing
- Air Intake Resonator and Duct
- Air Supply System
- Crankcase Vent Pipe
- EGR Pipe and Heat Shield
- EGR Modulator Valve and Manifold
- EGR Cooler
- Electronic Throttle Body Assembly
- Fuel Evaporative Pipe and Clamp
- Fuel Chamber, Damper and Cut Valve
- Fuel Filler Hose, Clamp, Cap and Pipe Fuel Lines
- Fuel Tank
- Vent Cover, Hose and Pipe
- Rollover Valve
- Two-Way Switch and Valve
- Turbo Air Bypass Valve
- Vapor Separator
- Vacuum Pipe Assembly
- Rear Cooling Unit Blower Motor
- Receiver/Dryer
- Accelerator Switch
- Accelerator Pedal Return Spring Switch
- Accelerator Pedal, Lever, Clip and Bracket
- Auto Transmission Oil Cooler
- Clutch Release
- Clutch Fork Boot and Return Spring
- Clutch Operating Cylinder
- Clutch Hydraulic Line and Gasket
- Clutch Master Cylinder and Connecting Link
- Clutch Pedal, Washer and Bushing
- Differential Dip Stick
- Speed Sensor
- Inhibitor Switch
- Paddle Shifter
- Key Lock Solenoid and Release Lever
- Oil Temperature Switch
- Park Switch
- Pilot Bearing
- Selector Cable, Linkage, Bushing and Clip
- Selector Cable Pin and Bushing
- Shift Lock Control Unit, Lever and Solenoid
- Stop Light Switch
- Transmission Revolution Sensor
- Connecting Link
- Crossmember Bushing
- Front Strut Mount, Cover and Spring
- Front Crossmember Support and Bracket
- Hub Bearing Unit
- Hub Bolt
- Blower Motor Resistor
- Blower Motor Transistor
- Brake Fluid Indicator Switch
- Cam Angle Sensor
- Circuit Board
- Clutch Switch
- Crank Angle Sensor
- Dash Warning Box
- Electric Parking Brake Actuator
- Duty Solenoid
- ECU Unit
- EGR Temperature Sensor
- Cruise Control Electronic Module
- Power Rear Gate Control Module
- Power Rear Gate Drive Motor
- Power Rear Gate Auto Closer
- Fuse Box
- Fuse Joint Box
- GPS Antenna
- Hand/Foot Brake Switch
- Headlamp Adjuster Switch
- Headlamp Adjuster Motor
- Headlight Illumination Sensor
- Auto Headlight Leveler CM
- Heater Blower Fresh Air Actuator
- Heater Blower Motor
- Rear Heater Blower
- Heater Mode Control Unit and Actuator
- Ignition Key Light
- Inner Lap Belt Switch
- Intake Air Temp Sensor
- Immobilizer Antenna and Transponder
- Key/Seatbelt Warning Chime
- Manifold Absolute Pressure Sensor
- Manual Transmission Neutral Switch
- Knock Sensor
- Multifunction Display
- Navigation Display
- Navigation Unit and Bracket
- Outside Temp. Sensor
- Oxygen Sensor
- Power Door Locks
- Power Seat Limit Switch
- Power Seat Linkage
- Power Seat Reclining Motor
- Power Seat Tilt Motors
- Power Seat Slide Rail Motor
- Power Sunroof Micro Switch and Control Unit
- Power Window Circuit Breaker
- Rear Window Washer Pump
- Rear Window Defogger Grid
- Rear Wiper Intermittent Unit
- Body Integrated Unit
- Rear Cooling Unit Switch
- Seatbelt Switch
- Seatbelt Warning Chime
- Shoulder Belt Switch
- Starter Interlock Switch
- Trunk Light Switch
- Turbo Air Temperature Sensor
- Turbo Boost Sensor
- Voltage Drop Resistor
- Warning Unit Display
- Wastegate Control Valve
- Window Regulators
- Center Console Latch
- Dash Speakers
- Front Seatbelt Set
- Radio
- Qi® Charging Pad[6]
- Front Seat Lift Frame and Side Rails
- Glove Box Latch and Striker
- Keyless Entry Transmitter
- Rear Shelf Speakers
- Security System Control and Receiver Modules
- Sunroof Track, Cable and Guide
- Third-Row Seatbelt Set
- Third-Row Seat Back Frame and Hinge
- Tire Pressure Monitoring System
- Transmitter and Control Module
- Valve Body

And many more components

*Added Security Gold Plus does not cover some components, including maintenance items, brake pads, windshield wiper blades, hoses, belts, batteries and more. Please see your Subaru retailer for specific component coverage details.

1 EyeSight is a driver assist technology, which may not operate optimally under all driving conditions. The driver is always responsible for safe and attentive driving. System effectiveness depends on many factors, such as vehicle maintenance, weather and road conditions. See your Owner's Manual for complete details on system operations and limitations. 2 Blind-Spot Detection, Lane Change Assist and Rear Cross-Traffic Alert are systems designed to assist the driver by monitoring the rear and side areas of the vehicle during a lane change or reversing and are not a substitute for safe and attentive driving. 3 The Reverse Automatic Braking System is not a substitute for safe and attentive driving. System effectiveness depends on many factors, such as vehicle maintenance, weather and road conditions. Always exercise caution and use vehicle mirrors and the Rear-Vision Camera when backing up. See your Owner's Manual for complete details on system operation and limitations. 4 The DriverFocus Distraction Mitigation System is a driver recognition technology designed to alert drivers if their attention to the road wavers or if the driver's face appears to turn away. The driver is always responsible for safe and attentive driving. System effectiveness may be affected by articles of clothing worn on the head or face. See your Owner's Manual for complete details on system and limitations. 5 Activation with subscription required. Includes a 3-year trial subscription to Safety Plus services and a 6-month trial subscription to Safety and Security Plus services. The Concierge plan can be purchased annually or monthly. A credit card on file will be required for specific packages and for renewal purposes. Not available in all states. See your Subaru retailer for details. 6 Qi® wireless charging may not be compatible with all mobile devices. When using the wireless charging system, avoid placing metal objects between the wireless charger and the mobile device when charging is active. Doing so may cause metal objects to become hot and could cause burns.

EyeSight and Subaru are registered trademarks of Subaru Corporation. Added Security and DriverFocus are registered trademarks of Subaru of America, Inc. STARLINK is a trademark of Subaru Corporation. Qi® is a registered trademark of Wireless Power Consortium, Inc.